



Open Metering System Specification

OMS-Data Point List

Annex B to Volume 2: Primary Communication Issue 5.0.1

RELEASE G (2023-12)

Document History

Version	Date	Comment	Editor
A 0.1.0	2013-09-25	Generation of first Draft	U.Pahl
A 0.2.0	2013-10-16	Update of OMS-DPL	U.Pahl
A 0.2.1	2013-10-17	Correction T.Banz	U.Pahl
A 0.2.2	2013-10-18	Foot note 15 for Heat/cooling	U.Pahl
A 0.2.3	2013-10-21	Bugfix	U.Pahl
A 0.3.0	2014-01-17	Changes according final vote	U.Pahl
A 0.3.1	2014-01-25	Rename VIF-Type->VIB-Type Release A	U.Pahl
B 0.4.0	2014-11-07	Add encryption requirements Add symbols Θ and φ	U.Pahl
B 4.1.0	2016-06-22	Add alternative optional description	Thomas Banz
C 4.2.0	2019-10-28	Add declaration of "No Data", "C", "C", "Ox", "Empty"; Footnote 16 and 17; Device type "Breaker / Valve"; MB-Tag Section "DC- Disconnecter Control", "YD-Descriptors"; MB- Tag "DC1!", "MM8!", "VM4!", "VM5!", "YD1!", "YD1!T", "YD2!P", "YD3!P"; VIB-Type section "CL-Control", "YD-Descriptor"; VIB-Types "MM07", "MM08", "MM09", "MM09", "MM10", "MM11", "VM07", "VM08", "VM09", "VM10", "YD01", "YD02", "YD03", "YD04", "YD05", "YD06", "YD07"	Thomas Banz
D 4.3.0	2020-06-03	Changed headline for B.2.2 New chapter B.2.3 Add conditions from OMS-S2, Annex M to "DC1!", "DT1!", "DT2!D", "EJ1!", "EJ1!T", "EJ2!", "EJ1!D", "EJ1!DT", "EJ2!D", "EW1!", "EW1!D", "EW1!T", "EW1!DT", "EW1!R", "EW1!RT", "EW2!D", "HC1!", "HC1!D", "MM2!", "MM3!", "TC1!", "TC2!", "VM1!", "VM1!D", "VM1!DT", "VM2!", "VM3!" Editorial changes	Thomas Banz, Achim Reissinger
D 4.3.1	2020-06-04	Editorial changes in B.2.3	Thomas Banz, Achim Reissinger
D 4.3.2	2020-06-04	Editorial changes	Uwe Pahl, Achim Reissinger
D 4.3.3	2020-06-05	Editorial changes	Thomas Banz, Achim Reissinger
D 4.3.4	2020-07-07	Updated title page Add VIB-Types CL02, HC02 Add group CT Add tags CT1!, XCL2!	AG1, Achim Reissinger
D 4.3.5	2020-07-09	Wording changed for CT, CT1!, XCL2!	Achim Reissinger
D 4.3.6	2020-09-24 and 2020-09-29 and 2020-10-02	Editorial changes Add "O1" in Col. Breaker for DT1! And DT2! Add two new MB-Tags: <ul style="list-style-type: none"> ID7! "Initial DIN address" with VarLen, T=0;F=0;X=0;FD=no and VIB Type=ID01 ID8! "Current DIN address" with VarLen, T=0;F=0;X=0;FD=no and VIB Type=ID02 	Achim Reissinger Uwe Pahl, Thomas Banz
D 4.3.7	2020-10-13	List of MB-Command-Tags: <ul style="list-style-type: none"> Add new group "Compliance Test Command" Change VIB Type Reference form CL02 to CT01 Change to XCL to XDC change Headline top "Disconnecter Control Command" 	Thomas Banz

Version	Date	Comment	Editor
		<ul style="list-style-type: none"> Change XCL1! To XDC1! <p>List of VIB-Types:</p> <ul style="list-style-type: none"> Add new group "Compliance Test" Move CL02 to CT01 Add CL02 	
D 4.3.8	2020-10-19	Release	Achim Reissinger
E 4.4.0	2021-10-21	<p>Add B.2.3 for sensors Update B.2.1, B.2.2, B.2.4 and B.3.1 for sensors</p> <p>Release candidate</p>	AG1, AG1 TF Sensors, Thomas Banz, Achim Reissinger
E 4.4.1	2021-12	<p>List of MB-Data-Tags:</p> <ul style="list-style-type: none"> Term for "temperature" corrected for TC1!, TC2!, TC3! Condition removed for VM1!DT <p>Release</p>	AG1, Thomas Banz Achim Reissinger
E 4.4.2	2022-01-31 and 2022-02-23 and 2022-05-30	<p>List of MB-Data-Tags:</p> <ul style="list-style-type: none"> Condition for PT5!..PT8! corrected Table footnote 23 added for EJ1!D, EJ1!DT, EW1!D, EW1!DT Colouring of Footnote 23 removed DP5! and DP6! set to optional for all devices <p>List of VIB-Types:</p> <ul style="list-style-type: none"> Add ER01 <p>Legend and Notes:</p> <ul style="list-style-type: none"> Declaration of "Time point (X and final DIFE(FD))" changed Line feed inside footnote 21 removed <p>Copyright remark added to front page</p> <p>Release</p>	Uwe Pahl, Thomas Banz, Achim Reissinger
F 4.5.0	2022-01-31 until 2022-10-15	<p>List of MB-Data-Tags:</p> <ul style="list-style-type: none"> Unit corrected for PT5!..PT8! Data Field for Get ID4 set to NoData Table footnote 23 added for DT2!D, EJ1!D, EJ1!DT, EJ2!D, EW1!D, EW1!DT, EW1!R, EW2!D, TC1!, TC2!, VM1!D Condition for UC-07 removed for EJ1!, EJ1!T, EJ2!, EW1!, EW1!T, EW2!, HC1!, HC1!D, VM1!, VM2!, VM3! Change to "last", Add Condition for DT2!D ST2!N and MM6! added <p>List of MB-Command-Tags:</p> <ul style="list-style-type: none"> Table footnote 24 added Change Data Field to "NoData" for getID4! Groups XDT, XVM, XEJ and XEW added getIDT2!D, getDT2!N, setDT2!N added XMM2!, XMM3!, XMM4! marked as valid until version 4.4.2 notMM2!, notMM3!, clrMM3! replace XMM2!, XMM3!, CMM4! 	AG1 Achim Reissinger

Version	Date	Comment	Editor
		<ul style="list-style-type: none"> • setID2!, setID10! and setID11! added • getMM6!, setMM6! added • General section added • arl***!, drr***! added • Type/Encryption: Change std. Text for this commands to "Command to device" <p>List of VIB-Types:</p> <ul style="list-style-type: none"> • Group ER added • ID04s, ID04g removed due to general rule • DT05, ID10, MM17 added <p>Legend and Notes:</p> <ul style="list-style-type: none"> • SelRead" removed <p>B.1.4 incl. tables 2 to 4 added</p> <p>Copyright remark added to front page</p> <p>Release Candidate</p>	
F 4.5.1	2022-11-08 to 2022-11-14	Integration of review comments	AG1, Achim Reissinger
F 4.5.2	2022-12-20	List of VIB-Types: ID10 deleted Release	Thomas Banz, Uwe Pahl, Achim Reissinger
G 4.6.0	2023-07-10 to 2023-11-03	<p>Action items #131-3, #132-3, #132-15 integrated</p> <p>Extension of rule for encryption of MB-Command-Tags in document</p> <p>New issue and version number</p> <p>Table index added</p> <p>Table numbering corrected</p> <p>List of MB-Data-Tags:</p> <ul style="list-style-type: none"> • CO Alarm Change Headline to "CO Alarm Device(1Dh)" • Heat Alarm Device(1Eh) Add column with entries • Conductivity Sensor Remove column • Heart Beat Sensor Remove column • Impedance Sensor Remove column • AD4! Add VIB-Type Reference AD14 • AD5! Add VIB-Type Reference AD15 • AD6! Add VIB-Type Reference AD16 • AD7! Add VIB-Type Reference AD17 • AD8! Add VIB-Type Reference AD18 • AD9! Add VIB-Type Reference AD19 • AD10! Add VIB-Type Reference AD20 • AD11! Add VIB-Type Reference AD21 • AD12! Add VIB-Type Reference AD22 	Thomas Banz, Uwe Pahl, Achim Reissinger

Version	Date	Comment	Editor
		<ul style="list-style-type: none"> • AD13! Add VIB-Type Reference AD23 • AD14! Add VIB-Type Reference DI03 • CC1! Add VIB-Type Reference CC03 • CC2! Add VIB-Type Reference CC04 • ID9! Change Reference to ID10, change marking for CO Alarm from "M" to "O" • IR1! Add VIB-Type Reference IR02 • LT1! Add VIB-Type Reference LT03 • LT2! Add VIB-Type Reference LT04 • MM12! Add VIB-Type Reference MM18 • MM13! Add VIB-Type Reference MM19 • MM14! Add VIB-Type Reference MM20 • MM15! Add VIB-Type Reference MM21 • MM16! Add VIB-Type Reference MM22 • MM17! Add Tag • MO1! Add VIB-Type Reference RH03 • ND1! Add VIB-Type Reference ND02 • PF1! Maked as "Valid only until OMS-S2 V4.5.1" • PH1! Add VIB-Type Reference PH02 • PT1! Add VIB-Type Reference PT09 • PT2! Add VIB-Type Reference PT10 • PT3! Add VIB-Type Reference PT11 and change description from "PM1.5" to "PM2.5" • PT4! Add VIB-Type Reference PT12 • PT5! Add VIB-Type Reference PT13 • PT6! Add VIB-Type Reference PT14 • PT7! Add VIB-Type Reference PT15 • PT8! Add VIB-Type Reference PT16 • RF1! Add VIB-Type Reference DI03 and DI04 • TB1! Add VIB-Type Reference TB02 • VC1! Add VIB-Type Reference VC03 • VC2! Add VIB-Type Reference VC04 • WS1! Add VIB-Type Reference WS02 • ID9! Closed lock symbol added • DP1!B, DT1!B, DT5!B, EJ1!B, EJ2!B, EW1!B, EW2!B, EW3!B, HC1!B, VM1!B, VM2!B, VM3!B added • EC added • EC1!, EC2!, EC1!D, EC2!D added • EC1!P, EC2!P added 	

Version	Date	Comment	Editor
		<ul style="list-style-type: none"> DT1!P, EJ1!P, EJ1!PT, EJ2!P, EW1!P, EW1!PT, EW2!P, EW3!P, HC1!P, VM1!P, VM2!P, VM3!P added HC1! change "M" to "A1" VM1! change "M" to "A1" for water and hot water ID11! remove encryption symbols for ID11! ID11! changed to ID10! EJ sort group to release mix of EJ1! And EJ2! <p>List of MB-Command-Tags:</p> <ul style="list-style-type: none"> XID2!, XID10! Add commands Col. B Remove Encryption in headline and encryption symbols at commands and groups XID11! Add command setID2! Correct Description XID2! Correct Description setID11! Correct VIB-Type reference (ID10 --> ID09) setID10!, setID11! Remove condition to OMS-S2 Annex M setID10!, setID11! Change Marking from "C" to "O" setID10!, setID11! Change Description setID10!, setID11! Set "setID10!" to "setID11!" and vice versa <p>List of MB-Data-Tags for sensors:</p> <ul style="list-style-type: none"> CO Alarm Change Headline to "CO Alarm Device(1Dh)" Heat Alarm Device (1Eh) Add column Conductivity Sensor Remove column Heart Beat Sensor Remove column Impedance Sensor Remove column PT3! Change description from "PM1.5" to "PM2.5" <p>List of VIB-Types:</p> <ul style="list-style-type: none"> FR01, PR01, PR02, PR03, PR04, PR05, PR06, PR07, PR08, RH01, TC04, PJ01 Add Remark AD14, AD15, AD16, AD17, AD18, AD19, AD20, AD21, AD22, AD23, CC03, CC04, DI03, DI04, ID10, IR02, LT03, LT04, MM18, MM19, MM20, MM21, MM22, MM23, ND02, PH02, PT09, PT10, PT11, PT12, PT13, PT14, PT15, PT16, RH03, TB02, VC03, VC04, WS02 Add VIB-Types ID09 Maked as "Valid only until OMS-S2 V4.5.1" PF01 Maked as "Valid only until OMS-S2 V4.5.1" ID09 Reactivate with description Device Type EW01 (ed): '000 0nnn' --> '0000 0nnn' EC Add EC01, EC02 Add 	

Version	Date	Comment	Editor
		Release candidate	
G 4.6.1	2023-12-10 to 2024-01-14	Consideration of review comments Release	AG1, Achim Reissinger

Contents

Document History.....	2
Contents.....	8
Tables	8
B.1 Overview about the OMS-Data Point List.....	9
B.1.1 General	9
B.1.2 The VIB-Type List	9
B.1.3 The M-Bus Tag List.....	9
B.1.4 M-Bus Commands	9
B.1.5 Legend and Notes.....	12
B.1.6 List of MB-Data-Tags	15
B.1.7 List of MB-Sensor-Tags.....	35
B.1.8 List of MB-Command-Tags.....	39
B.2 VIB-Type List	43
B.2.1 Legend and Notes.....	43
B.2.2 List of VIB-Types.....	44

Tables

Table B.1: Example of MB-Tag EW1!R	9
Table B.2: Command methods and their action code	10
Table B.3: Example for the VIB-Type extension of an M-Bus-Command tag with ID4!	10
Table B.4: Example for the VIB-Type extension of an M-Bus-Command tag with VM1!D	11

B.1 Overview about the OMS-Data Point List

B.1.1 General

The OMS-Data Point List (OMS-DPL) lists all harmonised M-Bus-Tags. An M-Bus Tag is an abstract description of one or several M-Bus data points, which may differ in scaler or resolution or data type (according to [EN13757-3:2018], Table 4).

The OMS-DPL consists of two lists:

- VIB-Type List (VTL)
- M-Bus Tag List (MBTL)

B.1.2 The VIB-Type List

A VIB-Type describes a physical unit with a scaler and an optional VIF property like direction of flow. Each VIB-Type in the VIB-Type-List is associated with one unique combination of VIF and VIFE.

Example: "EW02" means energy in Watt with special scaler 10^5 to 10^6 used only for imported energy.

B.1.3 The M-Bus Tag List

Each MB-Tag listed in the OMS-DPL is associated with a unique combination of Tarif "T", Function "F", Storage number "X", the final DIFE "FD" and a set of VIB-Types. The set of VIB-Types has always the same VIF-properties, the same physical unit, but may be different scalers or different data types. One MB-Tag can be used by different device types (e.g. EW1! – Energy in Watt is in use for Electricity, Heat and Cooling meters).

Example: MB-Tag EW1!R describes a recent value of energy used for billing. This MB-Tag declares

- a historical (recent) value by a set FD
- a register (declared by Storage number X)
- an instantaneous value (declared by function F=0)
- applies no tariff (T=0)
- Unit is always Watt (declared by the VIB-Type)
- The scaler has a range of 10^{-6} to 10^6 (declared by the VIB-Types EW01, EW02 and EW03)

Such a MB-Tag could be coded as shown in Table B.1.

Table B.1: Example of MB-Tag EW1!R

Example	DIF/DIFE	VIF/VIFE	Value
12,3 MWh (in register 5)	C2h 82h 00h	FBh 00h	7Bh 00h
12300 kWh (in register 5)	CBh 82h 00h	06h	00h 23h 01h

B.1.4 M-Bus Commands

M-Bus commands are represented by M-Bus-Command-Tags. The M-Bus-Command-Tag uses the same VIB-Type as an M-Bus-Data-tag. M-Bus Command-Tags are usually identified by a command action added to the VIB-Type.

NOTE 1: Some commands do not use a command action for historical reasons.

The used command actions shall be according to Table B.2.

Table B.2: Command methods and their action code

Command	Command action	Action code
Set value	set	00h
Add to value	add	01h
Subtract from value	sub	02h
Mask value with binary OR	bor	03h
Mask value with binary AND	and	04h
Mask value with binary XOR	xor	05h
Mask value with binary NOT AND	not	06h
Clear value	clr	07h
Add to readout-list ^a	arl	0Ch
Delete from readout-list ^a	drl	0Dh
Get value	get	0Fh
^a To add MB-Data-Tags to or delete them from the readout list, the OMS end-device shall support <ul style="list-style-type: none"> - the actually implemented VIB-Type and - the first VIB-Type in the column “VIB-Type Reference” of the MB-Data-Tag list, where all possibly coming “n” shall be set to 0 (see Table B.4 for an example). 		

The command action is represented in the M-Bus data point by an M-Bus action code according to Table B.2 (see also [EN13757-3:2018], 6.4.7).

The Action code shall be the last VIFE of the VIB type. To signal that the VIB-Type is being extended, the extension bit of the previous VIF(E) shall be set.

In case of a compact profile in a command tag the VIFE of the compact profile (13h, 1Eh or 1Fh) is the very last VIFE.

NOTE 2: As an M-Bus action code is added to the VIB type of a command, the M-Bus-Command-tag becomes one byte longer than the corresponding M-Bus-Data-tag.

OMS end-devices shall not send M-Bus Command-Tags.

Table B.3 and Table B.4 show examples for the VIB-Type extension of M-Bus-Command-Tags.

Table B.3: Example for the VIB-Type extension of an M-Bus-Command tag with ID4!

	M-Bus-Tag	VIB-Type	M-Bus data point in hex
M-Bus-Data-tag for “Ownership number” with value 123456	ID4!	ID04	0B FD 11 56 34 12
M-Bus-command-tag for “Set Ownership number” to 123456	setID4!	set[ID04]	0B FD 91 00 56 34 12
M-Bus-command-tag for “Get Ownership number”	getID4!	get[ID04]	00 FD 91 0F

Table B.4: Example for the VIB-Type extension of an M-Bus-Command tag with VM1!D

Note	M-Bus-Tag	VIB-Type	M-Bus data point in hex
M-Bus-Data-tag for “Volume (V), accumulated, total, due date value” with value 12345678	VM1!D	VM02 with nnn = 011 _b	4C 93 7D 78 56 34 12
M-Bus-command-tag for “Add Volume (V), accumulated, total, due date value to readout list”	ar!VM1!D	ar![VM01] with nnn = 000 _b	40 90 0C
M-Bus-command-tag for “Delete Volume (V), accumulated total, due date value from readout list”	del!VM1!D	del[VM02] with nnn as used by the meter	40 93 FD 0D

The communication partner shall use the communication security profile applied by the OMS end-device.

B.2 M-Bus Tag List

B.2.1 Legend and Notes

Data Field:

INT = Integer (8 Bit - 64 Bit) refer to [EN13757-3:2018], Table 4
8INT = 8 Bit Integer/Binary refer to [EN13757-3:2018], Table 4
64INT = 64 Bit Integer/Binary refer to [EN13757-3:2018], Table 4
BCD = Binary Coded Decimal refer to [EN13757-3:2018], Table 4
8BCD = 4 Byte BCD refer to [EN13757-3:2018], Table 4
VarLen = variable length refer to [EN13757-3:2018], Table 4
Type F = Compound CP32: Date and Time refer to [EN13757-3:2018], Annex A
Type G = Compound CP16: Date refer to [EN13757-3:2018], Annex A
Type I = Year down to second refer to [EN13757-3:2018], Annex A
Type J = Time of day refer to [EN13757-3:2018], Annex A
No Data = No Data refer to [EN13757-3:2018], Table 4

M = Mandatory (These data objects shall be provided.)

Ax = Alternatively (At least one of the with "A" and identical number marked data objects is mandatory.)

Xx = Exclusively alternatively (Precisely one of the with "X" and identical number marked data objects is mandatory.)

O = Optional (These data objects may or may not be provided.)

Ox = Optional alternatively (Only one of the with 'O' and identical number marked data objects are allowed in the datagram.)

C = Conditional (Mandatory if condition applies). If condition does not apply, optional 'O' is valid.

C Ox = Conditional or optional alternatively (mandatory if condition applies). If condition does not apply, optional alternatively 'Ox' is valid.

Empty = An empty field indicates that this MB-Tag is not applicable to this device type.


S = MB-Sensor-Tag, see chapter "List of MB-Sensor-Tags".


E = Exclusively use (Mandatory if condition applies. Otherwise it is not applicable to this device type.)


Encryption

The column "type" also shows the encryption requirements according to the selected security profile [OMS-S2], 9.1. In the headline of each value group a respective symbol can be found which is valid for each M-Bus-Tag below in this group. Only in case of exceptions a separate symbol is shown directly after the type definition of this single M-Bus-Tag (e.g. ID6!).

Symbols:

 = Encryption is mandatory.

 = Encryption is not required but can be used optionally.

 = Encryption is not allowed.

For data points that are not listed in the M-Bus Tag List encryption is optional. This includes manufacturer specific data. However, it is strongly recommended to encrypt all consumer relevant data.

The letters and numbers in front of the alert sign "!" declare the supported combination of VIB-Types. The letters after the alert sign are optional and declare additional conditions. Every letter after alert sign is used once only).

Declaration of Measurement condition (F)

- * [] instant
- * [A] maximum
- * [I] minimum
- * [E] Error condition

Declaration of Time point (X and final DIFE(FD))

- * [] current value (X=0)
- * [B] usage according [OMS-S2] Annex R (see also [OMS-S2] Annex G), (X=3)
- * [D] due date value (X=1)
- * [N] next date (X=1)
- * [P] periodical values (X=8..199)
- * [R] Recent value (X=0..99, 101..124 + final DIFE)
- * [C] cumulative value of a maximum/minimum
- * [Xn] Sporadic event, where n is the value of used Storage number (X = 3..31) e.g. 'X3'

Declaration of Tarif-Register (T)

- * [] No tarif
- * [T] Tariff 1..15

Example: 1-0:1.6.e*f "Actual maximum of active power import (+P), recent value for billing, total (value + time stamp)" is coded as "DT1!ART".

¹⁰ This MB-Tag is several times used. The description for this MB-Tag depends on the device type of the transmitting OMS end-device.

¹¹ Recent values are always coded with a final DIFE with the value 00h. The number of DIFEs is variable. For downward compatibility reasons and for realization of constant data record length it is allowed to use more DIFEs (between the DIF and the final DIFE = 00h) than necessary.

¹² Depending on Data field: Identification number (8BCD) or Application Layer Address (64INT)
Order of Application Layer Address (ALA) according [EN13757-7:2018], Table 12.

¹⁴ Refer to [EN13757-3:2018], Annex E.1

¹⁵ For device type comb. Heat/Cooling the tariff 1 is allowed only!

¹⁶ According to [EN13757-3:2018], Annex C.3, subunit must be 1 if the disconnecter is integrated into a meter.

¹⁷ The subunit of the subunit descriptor shall be >0.

¹⁹ VarLen with a 14 characters ASCII string (LSB first) according to [EN13757-3:2018], Table 5. For example, the address in [OMS-S2], Table 5 is coded as: 0D 78 0E 34 34 33 33 32 32 31 31 31 30 53 44 51 37

²¹ The OMS end-device shall provide this MB-Tag in a static datagram (according to OMS-S2, 4.3.2.4).

²² VarLen with binary value range (E0h – EFh)


²³ Related M-Bus-Data-Tags may only be transmitted in the consumer information messages (content index 3).






²⁴ VIB-Type references enclosed in square brackets are extended with the given action code according to subclause B.1.4.



²⁵ The periodical values shall fulfill minimum data granularity and update interval maximum according to [OMS-S2], 4.3.2.2., Table 8.

²⁶ This data point is for device type comb. heat/cooling meter (0Dh) expected to be deprecated in the future.













B.2.2 List of MB-Data-Tags




Type Encryption	MB-Tag	Description	Data field	Tariff [T]	Func- tion [F]	Storage [X]	Final DIFE [FD] ¹¹	VIB-Type Reference	Electricity (02h)	HCA (08h)	Cooling (0Ah;0Bh)	Comb. Heat/Cooling (0Dh)	Heat (04h;0Ch)	Gas (03h)	Cold Water (07h;16h)	Hot Water (06h;15h)	Breaker / Valve (20h; 21h)	Sensor Device
	AD	Alarm Devices																
Sensor reading	AD4!	Number of dismounts / removal counter	INT, BCD	0	0	4	no	AD04, AD14										S
Sensor reading	AD5!	Number of test button operated counter	INT, BCD	0	0	5	no	AD05, AD15										S
Sensor reading	AD6!	Number of alarms	INT, BCD	0	0	6	no	AD06, AD16										S
Sensor reading	AD7!	Number of alarm mute switch operated counter	INT, BCD	0	0	7	no	AD07, AD17										S
Sensor reading	AD8!	Number of obstacle detected counter	INT, BCD	0	0	8	no	AD08, AD18										S
Sensor reading	AD9!	Number of smoke entries blocked	INT, BCD	0	0	9	no	AD09, AD19										S
Sensor reading	AD10!	Number of smoke chamber defects	INT, BCD	0	0	10	no	AD10, AD20										S
Sensor reading	AD11!	Number of self-test failed counter	INT, BCD	0	0	11	no	AD11, AD21										S
Sensor reading	AD12!	Number of sounder defect counter	INT, BCD	0	0	12	no	AD12, AD22										S



Sensor reading	AD13!	Chamber Pollution Level	INT, BCD	0	0	13	no	AD13, AD23											S
Sensor reading	AD14!	Obstacle check distance	INT, BCD	0	0	14	no	DI01, DI02, DI03											S
	CA	Current [A]																	
Meter reading	CA1!	Current at phase L1, instantaneous value	INT, BCD	0	0	0	no	CA01	O										
Meter reading	CA2!	Current at phase L2, instantaneous value	INT, BCD	0	0	0	no	CA02	O										
Meter reading	CA3!	Current at phase L3, instantaneous value	INT, BCD	0	0	0	no	CA03	O										
Meter reading	CA4!	Current at neutral L0, instantaneous value	INT, BCD	0	0	0	no	CA04	O										
	CC	Carbon Oxide Content																	
Sensor reading	CC1!	Carbon monoxide content	INT, BCD	0	0	0	no	CC01, CC03											S
Sensor reading	CC2!	Carbon dioxide content	INT, BCD	0	0	0	no	CC02, CC04											S
	CD	Conductivity																	
Sensor reading	CD1!	Electrical conductivity	INT, BCD	0	0	0	no	CD01											S
	CT	Compliance test																	
	CT1!	Compliance test function <i>Condition: See OMS-S2 Annex M OMS-UC-00</i>	INT, VarLen	0	0	0	no	CT01	C	C	C	C	C	C	C	C	C	C	
	DC	Disconnecter Control																	
Meter/actuator reading	DC1!	Control state of breaker/valve ¹⁶ <i>Condition: See OMS-S2 Annex M OMS-UC-03</i>	INT	0	0	0	no	CL01	C					C	C	C	M		

Meter/actuator reading	DC2!	Actual physical state of breaker/valve ¹⁶ <i>Condition: See OMS-S2 Annex M OMS-UC-03</i>	INT	0	0	0	no	CL02	C						C	C	C	M	
 DP	DP	Duration/Period																	
Time, date of reading ¹⁰	DP1!	Run time difference between measurement of current value and transmission <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no	DP01	C	C	C	C	C	C	C	C	C		
Time, date of reading	DP1!B	Run time difference between meter value and its transmission <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	DP01	E		E	E	E	E	E	E	E		
Time integral ¹⁰	DP2!	Averaging duration for actual value	INT, BCD	0	0	0	no	DP02	O		O	O	O	O	O	O	O		
Transmission interval	DP3!	Nominal period of synchronous transmission	INT, BCD	0	0	0	no	DP03	O	O	O	O	O	O	O	O	O		
-	DP4!	Valid only until OMS-S2 V4.1.2. => Replaced by YD2!P	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Run time of OMS end-device	DP5!	Operating Time	INT, BCD	0	0	0	no	DP05	O	O	O	O	O	O	O	O	O	O	S
Run time of OMS end-device	DP6!	On Time	INT, BCD	0	0	0	no	DP06	O	O	O	O	O	O	O	O	O	O	S
 DT	DT	Date / Time (Time stamp)																	
Date/Time of OMS-end device ¹⁰	DT1!	Current date/time at time of transmission <i>Condition: See OMS-S2 Annex M OMS-UC-04</i>	Type F,I	0	0	0	no	DT01	C O1	C O1	C O1	C O1	C O1	C O1	C O1	C O1	C O1	C O1	S
Time, date of reading	DT1!B	Local date at time of meter value <i>Exclusive condition: See OMS-S2 Annex R</i>	Type F,I	0	0	3	no	DT01	E		E	E	E	E	E	E	E		

Time, date of reading ¹⁰	DT1!R	Local date at time of recent meter value	Type F,I	0	0	0..99, 101..124	yes	DT01	O2					O2				
Date/Time of reading ^{10 25}	DT1!P	Date/time of periodic meter value <i>Condition: See OMS-S2 Clause 4.3.2.2</i>	Type F,I	0	0	8..199	no	DT01	C	C	C	C	C	C	C	C		
Date, time of max. 🗄	DT1!A	Point of time of actual maximum of active power import (+P), current value, total	Type F,I	0	1	0	no	DT01	O3									
Date, time of max. 🗄	DT1!AR	Point of time of actual maximum of active power import (+P). recent value, total	Type F,I	0	1	0..99, 101..124	yes	DT01	O5									
Date, time of max. 🗄	DT1!AT	Point of time of actual maximum of active power import (+P), current value, tariff 1..15	Type F,I	1..15	1	0	no	DT01	O4									
Date, time of max. 🗄	DT1!ART	Point of time of actual maximum of active power import (+P). recent value, tariff 1..15	Type F,I	1..15	1	0..99, 101..124	yes	DT01	O6									
Date, time of event 🗄	DT1!Xn	Date / Time of related sporadic event	Type F,I	0	0	3..31	no	DT01										S
Date of reading ¹⁰	DT2!R	Local date at time of recent meter value	Type G	0	0	0..99, 101..124	yes	DT02	O2					O2				
Date of OMS end-device ¹⁰	DT2!	Current date at time of transmission	Type G	0	0	0	no	DT02	O1	O1	O1	O1	O1	O1	O1	O1	O1	S
Date of reading ¹⁰	DT2!D	Local date at last due date <i>Condition - 1: See OMS-S2 Annex M OMS-UC-07²³</i> <i>Condition - 2: See OMS-S2 Annex M OMS-UC-12a</i> <i>Condition - 3: See OMS-S2, 8.4.5.1</i>	Type G	0	0	1	no	DT02		M	C	C	C		C	C		
Date of reading ¹⁰	DT2!N	Local date at next due date <i>Condition: See OMS-S2 Annex M OMS-UC-12a</i>	Type G	0	0	1	no	DT05		C	C	C	C		C	C		


Date of max. 	DT2!A	Point of time of actual maximum of active power import (+P), current value, total	Type G	0	1	0	no	DT02	O3										
Date of max. 	DT2!AR	Point of time of actual maximum of active power import (+P), recent value, total	Type G	0	1	0..99, 101..124	yes	DT02	O5										
Date of max. 	DT2!AT	Point of time of actual maximum of active power import (+P), current value, tariff 1..15	Type G	1..15	1	0	no	DT02	O4										
Date of max. 	DT2!ART	Point of time of actual maximum of active power import (+P), recent value, tariff 1..15	Type G	1..15	1	0..99, 101..124	yes	DT02	O6										
Date of event 	DT2!Xn	Date of related sporadic event	Type G	0	0	3..31	no	DT02											S
Date, time of max. 	DT3!A	Point of time of actual maximum of active power export (-P), current value, total	Type F,I	0	1	0	no	DT03	O7										
Date, time of max. 	DT3!AR	Point of time of actual maximum of active power export (-P), recent value, total	Type F,I	0	1	0..99, 101..124	yes	DT03	O8										
Date, time of max. 	DT3!AT	Point of time of actual maximum of active power export (-P), current value, tariff 1..15	Type F,I	1..15	1	0	no	DT03	O9										
Date, time of max. 	DT3!ART	Point of time of actual maximum of active power export (-P), recent value, tariff 1..15	Type F,I	1..15	1	0..99, 101..124	yes	DT03	O10										
Date of max. 	DT4!A	Point of time of actual maximum of active power export (-P), current value, total	Type G	0	1	0	no	DT04	O7										
Date of max. 	DT4!AR	Point of time of actual maximum of active power export (-P), recent value, total	Type G	0	1	0..99, 101..124	yes	DT04	O8										
Date of max. 	DT4!AT	Point of time of actual maximum of active power export (-P), current value, tariff 1..15	Type G	1..15	1	0	no	DT04	O9										






Date of max. 	DT4!ART	Point of time of actual maximum of active power export (-P), recent value, tariff 1..15	Type G	1..15	1	0..99, 101..124	yes	DT04	O 10										
Time of OMS end-device ¹⁰	DT5!	Current time at time of transmission	Type J	0	0	0	no	DT01	O1										
Time of OMS end-device	DT5!B	Local time at time of meter value <i>Exclusive condition: See OMS-S2 Annex R</i>	Type J	0	0	3	no	DT01	E			E	E	E	E	E	E		
	EC	Energy in calorie																	
Meter reading ¹⁰	EC1!	Energy import	INT, BCD	0	0	0	no	EC01				O	O	O					
Meter reading ¹⁰	EC1!D	Energy import <i>Condition: See OMS-S2 Annex M OMS-UC-07 ²³</i>	INT, BCD	0	0	1	no	EC01				C O	C O	C O					
Meter reading ^{10 25}	EC1!P	Energy, periodical value, import	INT, BCD	0	0	8..199	no	EC01				O	O	O					
Meter reading	EC2!	Energy import (2nd value for cooling), current value in calorie, total	INT, BCD	0	0	0	no	EC02					O						
Meter reading	EC2!D	Energy import (2nd value for cooling), due date value in calorie, total <i>Condition: See OMS-S2 Annex M OMS-UC-07 ²³</i>	INT, BCD	0	0	1	no	EC02					C O						
Meter reading ²⁵	EC2!P	Energy import (2nd value for cooling), periodical value in calorie, total	INT, BCD	0	0	8..199	no	EC02					O						
	EJ	Energy in Joule																	
Meter reading ¹⁰	EJ1!	Energy import	INT, BCD	0	0	0	no	EJ01, EJ02, EJ03				X1	X1	X1					
Meter reading ¹⁰	EJ1!B	Energy import <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	EJ01, EJ02, EJ03				E	E	E					







Meter reading ¹⁵	EJ1!T ²⁶	Energy import (2nd value for cooling), current value in Joule, total	INT, BCD	1	0	0	no	EJ01, EJ02, EJ03,				X2						
Meter reading ^{10 25}	EJ1!P	Energy, periodical value, import	INT, BCD	0	0	8..199	no	EJ01, EJ02, EJ03				O7	O7	O7				
Meter reading ¹⁰	EJ1!D	Energy import <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	1	no	EJ01, EJ02, EJ03				C O3	C O3	C O3				
Meter reading	EJ1!DT ²⁶	Energy import (2nd value for cooling), due date value in Joule, total <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	1	0	1	no	EJ01, EJ02, EJ03,				C O5						
Meter reading	EJ2!	Energy import (2nd value for cooling), current value in Joule, total	INT, BCD	0	0	0	no	EJ04, EJ05, EJ06,				X2						
Meter reading	EJ2!B	Energy import (2nd value for cooling), current value in Joule, total <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	EJ04, EJ05, EJ06,				E						
Meter reading	EJ2!D	Energy import (2nd value for cooling), due date value in Joule, total <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	1	no	EJ04, EJ05, EJ06,				C O6						
Meter reading ²⁵	EJ2!P	Energy import (2nd value for cooling), periodical value in Joule, total	INT, BCD	0	0	8..199	no	EJ04, EJ05, EJ06,				O8						
	ER	Electrical Resistance																
Sensor reading	ER1!	Electrical Resistance	INT, BCD	0	0	0	no	ER01										S
	EW	Energy in Watt hour																
Meter reading ¹⁰	EW1!	(Active) energy import	INT, BCD	0	0	0	no	EW01, EW02, EW03	A1			X1	X1	X1				



















Meter reading ¹⁰	EW1!B	(Active) energy import <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	EW01, EW02, EW03	E		E		E					
Meter reading ¹⁰	EW1!D	Energy import <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	1	no	EW01, EW02, EW03			C O3	C O3	C O3					
Meter reading ^{10 15}	EW1!T ²⁶	(Active) energy import	INT, BCD	1..15	0	0	no	EW01, EW02, EW03	O			X2						
Meter reading	EW1!DT ²⁶	Energy import (2nd value for cooling), due date value in Watt, total <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	1	0	1	no	EW01, EW02, EW03				C O5						
Meter reading ^{10 25}	EW1!P	(Active) energy, periodical value, import	INT, BCD	0	0	8..199	no	EW01, EW02, EW03	O		O7	O7	O7					
Meter reading	EW1!R	Active energy import (+A), recent value for billing in Watt, total <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	0..99, 101..124	yes	EW01, EW02, EW03	C									
Meter reading	EW1!RT	Active energy import (+A), recent value for billing in Watt, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	EW01, EW02, EW03	O									
Meter reading ¹⁰	EW2!	Energy export for electricity/energy import (2nd value for cooling) for comb. heat/cooling	INT, BCD	0	0	0	no	EW04, EW05, EW06	A1			X2						
Meter reading ¹⁰	EW2!B	Energy export for electricity/energy import (2nd value for cooling) for comb. heat/cooling <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	EW04, EW05, EW06	E			E						


Meter reading	EW2!D	Energy import (2nd value for cooling), due date value in Watt, total <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	1	no	EW04, EW05, EW06				C O6						
Meter reading	EW2!T	Active energy export (-A), current value in Watt, tariff 1-15	INT, BCD	1..15	0	0	no	EW04, EW05, EW06	O									
Meter reading 10 25	EW2!P	energy, periodical value	INT, BCD	0	0	8..199	no	EW04, EW05, EW06	O			O8						
Meter reading	EW2!R	Active energy export (-A), recent value for billing in Watt, total	INT, BCD	0	0	0..99, 101..124	yes	EW04, EW05, EW06	O									
Meter reading	EW2!RT	Active energy export (-A), recent value for billing in Watt, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	EW04, EW05, EW06	O									
Meter reading	EW3!	Active energy import (abs.(A)), current value in Watt, total	INT, BCD	0	0	0	no	EW07, EW08, EW09	A1									
Meter reading	EW3!B	Active energy import (abs.(A)), current value in Watt, total <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	EW07, EW08, EW09	E									
Meter reading	EW3!T	Active energy import (abs.(A)), current value in Watt, tariff 1-15	INT, BCD	1..15	0	0	no	EW07, EW08, EW09	O									
Meter reading 25	EW3!P	Active energy import (abs.(A)), periodical value in Watt, total	INT, BCD	0	0	8..199	no	EW07, EW08, EW09	O									
Meter reading	EW3!R	Active energy import (abs.(A)), recent value for billing in Watt, total	INT, BCD	0	0	0..99, 101..124	yes	EW07, EW08, EW09	O									
Meter reading	EW3!RT	Active energy import (abs.(A)), recent value for billing in Watt, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	EW07, EW08, EW09	O									
	FR	Frequency																


Meter reading	FR1!	Supply frequency, instantaneous value	INT, BCD	0	0	0	no	FR01	O										
	HC	Heat coast allocation units																	
Meter reading	HC1!	Unrated integral, current value	INT, BCD	0	0	0	no	HC01, HC02	M										
Meter reading	HC1!D	Unrated integral, due date value	INT, BCD	0	0	1	no	HC01	M										
Meter reading ²⁵	HC1!P	Unrated integral, periodical value	INT, BCD	0	0	8..199	no	HC01, HC02	O										
	ID	Identification																	
Fabrication number	ID1!	Serial number (not changeable number assigned by the manufacturer)	8BCD	0	0	0	no	ID01	O	O	O	O	O	O	O	O	O	O	S
(Enhanced) identification ¹²	ID2!	Identification number or full Application Layer Address	64INT, 8BCD	0	0	0	no	ID02	O	O	O	O	O	O	O	O	O	O	S
Primary address	ID3!	One byte Link Layer Address	8INT	0	0	0	no	ID03	O	O	O	O	O	O	O	O	O	O	S
Ownership number 	ID4!	Ownership number	INT, BCD, VarLen	0	0	0	no	ID04	O	O	O	O	O	O	O	O	O	O	S
Metering point ID 	ID5!	Identification of the metering point	INT, BCD, VarLen	0	0	0	no	ID05	O	O	O	O	O	O	O	O	O	O	S
Unique message identification 	ID6!	Unique message identification	INT	0	0	0	no	ID06	O	O	O	O	O	O	O	O	O	O	S
DIN address	ID7!	Initial DIN address	VarLen ¹⁹	0	0	0	no	ID01	O	O	O	O	O	O	O	O	O	O	S
DIN address	ID8!	Current DIN address	VarLen ¹⁹	0	0	0	no	ID02	O	O	O	O	O	O	O	O	O	O	S
	ID9!	Valid only until OMS-S2 V4.5.1. => Replaced by ID11!																	
Device type information	ID10!	Device type	8INT	0	0	0	no	ID09	O	O	O	O	O	O	O	O	O	O	






Device type information 	ID11!	Sub Device Types	VarLen ²²	0	0	0	no	ID10											S
	IR	Irradiance																	
Sensor reading	IR1!	Irradiance, Radiant flux density	INT, BCD	0	0	0	no	IR01, IR02											S
	LT	Light																	
Sensor reading	LT1!	Illuminance	INT, BCD	0	0	0	no	LT01, LT03											S
Sensor reading	LT2!	Luminous intensity	INT, BCD	0	0	0	no	LT02, LT04											S
 	MM	Meter Management																	
Quality of Service	MM1!	Reception level	INT, BCD	0	0	0	no	MM01	O	O	O	O	O	O	O	O	O	O	S
Quality of Service	MM1!I	Quality limit of reception level	INT, BCD	0	2	0	no	MM01	O	O	O	O	O	O	O	O	O	O	S
Quality of Service	MM1!E	Noise level	INT, BCD	0	3	0	no	MM01	O	O	O	O	O	O	O	O	O	O	S
Error	MM2!	Error flags <i>Condition: See OMS-S2 Annex M OMS-UC-06</i>	INT	0	0	0	no	MM02	C	C	C	C	C	C	C	C	C	C	S
Error	MM3!	Error flags (standard) ¹⁴ <i>Condition: See OMS-S2 Annex M OMS-UC-06</i>	INT	0	0	0	no	MM03	C	C	C	C	C	C	C	C	C	C	S
Operator data	MM4!	Operator specific data (reserved for the operator)	INT, BCD, VarLen	0	0	0	no	MM04	O	O	O	O	O	O	O	O	O	O	S
-	MM5!	Valid only until OMS-S2 V4.1.2. => Replaced by YD3!P	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
	MM6!	Currently selected application <i>Condition: See OMS-Se Annex M OMS-UC-14</i>	INT	0	0	0	no	MM17	C	C	C	C	C	C	C	C	C	C	S
Meter reading 	MM7!	Cumulation counter (contains the last written register)	INT	0	0	0	no	MM06	O										





OMS end-device information	MM8!	Remaining battery lifetime	INT, BCD	0	0	0	no	MM09, MM10	O	O	O	O	O	O	O	O	O	S
 Sensor reading	MM12!	Battery status	INT, BCD	0	0	0	no	MM12, MM18										S
 Sensor status	MM13!	Status bits for pressure sensor	INT	0	0	0	no	MM13, MM19										S
 Sensor status	MM14!	Status bits for CO alarm devices	INT	0	0	0	no	MM14, MM20										S
 Sensor status	MM15!	Status bits for smoke alarm devices	INT	0	0	0	no	MM15, MM21										S
 Sensor status	MM16!	Status bits for "Door/Window Contact Sensor" and "Locked Door/Window Detector"	INT	0	0	0	no	MM16, MM22										S
 Sensor status	MM17!	Status bits for heat alarm device	INT	0	0	0	no	MM23										S
	MO	Moisture																
 Sensor reading	MO1!	Moisture in %	INT, BCD	0	0	0	no	RH02, RH03										S
	ND	Noise																
 Sensor reading	ND1!	Noise	INT, BCD	0	0	0	no	ND01, ND02										S
	PD	Phase in Degree																
Meter reading	PD1!	Angle between voltage on phase L1 and L2, instantaneous value	INT, BCD	0	0	0	no	PD01	O									
Meter reading	PD2!	Angle between voltage on phase L2 and L3, instantaneous value	INT, BCD	0	0	0	no	PD02	O									
Meter reading	PD3!	Angle between voltage on phase L3 and L1, instantaneous value	INT, BCD	0	0	0	no	PD03	O									
Meter reading	PD4!	Angle between voltage and current on phase L1, instantaneous value	INT, BCD	0	0	0	no	PD04	O									
Meter reading	PD5!	Angle between voltage and current on phase L2, instantaneous value	INT, BCD	0	0	0	no	PD05	O									

Meter reading	PD6!	Angle between voltage and current on phase L3, instantaneous value	INT, BCD	0	0	0	no PD06	O										
	PF	Pulse frequency																
	PF1!	Valid only until OMS-S2 V4.5.1																
	PH	pH value																
Sensor reading	PH1!	pH value	INT, BCD	0	0	0	no PH01, PH02											S
	PJ	Power in Joule per hour																
Power ¹⁰	PJ1!	Power (energy flow) (P), average, current value <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no PJ01			O2	O2	O2						
Power	PJ1!T ²⁶	Power (energy flow) (P), average, current value, tarif 1	INT, BCD	1	0	0	no PJ01				O4							
	PR	Pressure																
Base pressure	PR1!	defined Pressure, absolute, at base conditions (p _b)	INT, BCD	0	0	0	no PR01, PR02						O					S
Pressure	PR2!	Defined pressure, absolute	INT, BCD	0	0	0	no PR03, PR04											S
Pressure	PR3!	Upper pressure threshold	INT, BCD	0	0	0	no PR05, PR06											S
Pressure	PR4!	Lower pressure threshold	INT, BCD	0	0	0	no PR07, PR08											S
	PT	Particles																
Sensor reading	PT1!	Particles as unspecific range [µg/m3]	INT, BCD	0	0	0	no PT01, PT09											S
Sensor reading	PT2!	Particles as PM1 [µg/m3]	INT, BCD	0	0	0	no PT02, PT10											S
Sensor reading	PT3!	Particles as PM2.5 [µg/m3]	INT, BCD	0	0	0	no PT03, PT11											S
Sensor reading	PT4!	Particles as PM10 [µg/m3]	INT, BCD	0	0	0	no PT04, PT12											S


Sensor reading	PT5!	Particles as unspecific range [10e5/m ³]	INT, BCD	0	0	0	no	PT05, PT13											S
Sensor reading	PT6!	Particles as PM1 [10e5/m ³]	INT, BCD	0	0	0	no	PT06, PT14											S
Sensor reading	PT7!	Particles as PM2.5 [10e5/m ³]	INT, BCD	0	0	0	no	PT07, PT15											S
Sensor reading	PT8!	Particles as PM10 [10e5/m ³]	INT, BCD	0	0	0	no	PT08, PT16											S
	PW	Power in Watt																	
Meter reading ¹⁰	PW1!	Active power, current value <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no	PW01	O		O2	O2	O2						
Meter reading	PW1!T ²⁶	Power (energy flow) (P), average, current value, tariff1	INT, BCD	1	0	0	no	PW01				O4							
Meter reading	PW1!A	Actual maximum of active power import (+P), current value, total	INT, BCD	0	1	0	no	PW01	O										
Meter reading	PW1!AT	Actual maximum of active power import (+P), current value, tariff 1..15	INT, BCD	1..15	1	0	no	PW01	O										
Meter reading	PW1!AR	Actual maximum of active power import (+P), recent value for billing, total	INT, BCD	0	1	0..99, 101..124	yes	PW01	O										
Meter reading	PW1!ART	Actual maximum of active power import (+P), recent value for billing, tariff 1..15	INT, BCD	1..15	1	0..99, 101..124	yes	PW01	O										
Meter reading	PW3!	Active power export (-P), current value <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no	PW03	C										
Meter reading	PW3!A	Actual maximum of active power export (-P), current value, total	INT, BCD	0	1	0	no	PW03	O										
Meter reading	PW3!AT	Actual maximum of active power export (-P), current value, tariff 1..15	INT, BCD	1..15	1	0	no	PW03	O										



Meter reading	PW3!AR	Actual maximum of active power export (-P), recent value for billing, total	INT, BCD	0	1	0..99, 101..124	yes	PW03	O										
Meter reading	PW3!ART	Actual maximum of active power export (-P), recent value for billing, tariff 1..15	INT, BCD	1..15	1	0..99, 101..124	yes	PW03	O										
Meter reading	PW4!AC	Cumulative maximum of active power import (+P), total	INT, BCD	0	1	0	no	PW04	O										
Meter reading	PW4!ACT	Cumulative maximum of active power import (+P), tariff 1-15	INT, BCD	1..15	1	0	no	PW04	O										
Meter reading	PW6!AC	Cumulative maximum of active power export (-P), total	INT, BCD	0	1	0	no	PW06	O										
Meter reading	PW6!ACT	Cumulative maximum of active power export (-P), tariff 1-15	INT, BCD	1..15	1	0	no	PW06	O										
Meter reading	PW7!	Active power absolute (P), instantaneous value, total <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no	PW07, PW08	C										
Meter reading	PW8!	Active power absolute (P), instantaneous value, total	INT, BCD	0	0	0	no	PW09, PW10	O										
	RE	Reactive Energy																	
Meter reading	RE1!	Reactive energy import (+R), current value, total	INT, BCD	0	0	0	no	RE01, RE02	O										
Meter reading	RE1!T	Reactive energy import (+R), current value, tariff 1-15	INT, BCD	1..15	0	0	no	RE01, RE02	O										
Meter reading	RE1!R	Reactive energy import (+R), recent value for billing, total	INT, BCD	0	0	0..99, 101..124	yes	RE01, RE02	O										
Meter reading	RE1!RT	Reactive energy import (+R), recent value for billing, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	RE01, RE02	O										
Meter reading	RE2!	Reactive energy export (-R), current value, total	INT, BCD	0	0	0	no	RE03, RE04	O										
Meter reading	RE2!T	Reactive energy export (-R), current value, tariff 1-15	INT, BCD	1..15	0	0	no	RE03, RE04	O										

Meter reading	RE2!R	Reactive energy export (-R), recent value for billing, total	INT, BCD	0	0	0..99, 101..124	yes	RE03, RE04	O										
Meter reading	RE2!RT	Reactive energy export (-R), recent value for billing, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	RE03, RE04	O										
	RF	Rainfall																	
Sensor reading	RF1!	Rainfall	INT, BCD	0	0	0	no	DI01, DI03, DI04											S
	RH	Relative Humidity																	
Sensor reading	RH1!	Relative Humidity in %	INT, BCD	0	0	0	no	RH01											S
	RP	Reactive Power																	
Meter reading	RP1!	Reactive power import (+Q), current value	INT, BCD	0	0	0	no	RP01	O										
Meter reading	RP2!	Reactive power export (-Q), current value	INT, BCD	0	0	0	no	RP02	O										
	TB	Turbidity																	
Sensor reading	TB1!	Turbidity	INT, BCD	0	0	0	no	TB01, TB02											S
	TC	Temperature in °C																	
Temperature ¹⁰	TC1!	Flow temperature, current value <i>Condition: See OMS-S2 Annex M OMS-UC-07 ²³</i>	INT, BCD	0	0	0	no	TC01		O	C	C	C						
Temperature ¹⁰	TC2!	Return temperature, current value <i>Condition: See OMS-S2 Annex M OMS-UC-07 ²³</i>	INT, BCD	0	0	0	no	TC02		O	C	C	C						S
Base temperature	TC3!	defined Temperature, absolute, at base conditions (T _b) or for conversion (T _{tc})	INT, BCD	0	0	0	no	TC03						O					
Sensor reading	TC4!	External Temperature	INT, BCD	0	0	0	no	TC04											S

Sensor reading	TC5!	Minimum temperature limit value	INT, BCD	0	2	0	no TC05											S
Sensor reading	TC6!	Maximum temperature limit value	INT, BCD	0	1	0	no TC05											S
	TS	Tension																
Sensor reading	TS1!	Tension	INT, BCD	0	0	0	no TS01											S
	VC	VOC Content																
Sensor reading	VC1!	VOC Content [ppb]	INT, BCD	0	0	0	no VC01, VC03											S
Sensor reading	VC2!	VOC Content [µg/m3]	INT, BCD	0	0	0	no VC02, VC04											S
	VF	Volume Flow																
Flow rate ¹⁰	VF1!	Flow rate <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no VF01			O	O	O	O	O	O	O		S
Flow rate	VF1!T ²⁶	Flow rate, average (Va/t), current value, tariff 1	INT, BCD	1	0	0	no VF01			O								
Flow rate	VF2!	Flow rate <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no VF02						C					
Flow rate	VF3!	Flow rate <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	INT, BCD	0	0	0	no VF03						C					
	VM	Volume in m³																
Meter reading ¹⁰	VM1!	Volume, current value, total	INT, BCD	0	0	0	no VM01, VM02			O	O	O	A1	M	M			
Meter reading ¹⁰	VM1!B	Volume, current value, total <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no VM01, VM02						E	E	E			

Meter reading ¹⁰	VM1!D	Volume (V), accumulated, total, due date value <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	INT, BCD	0	0	1	no	VM01, VM02			O	O	O		C	C		
Meter reading ^{10 15}	VM1!T ²⁶	Volume, current value, tariff	INT, BCD	1..15	0	0	no	VM01, VM02				O		O				
Meter reading	VM1!DT ²⁶	Volume (V), accumulated, due date value, tariff 1 (2nd value for cooling)	INT, BCD	1	0	1	no	VM01, VM02				O						
Meter reading ^{10 25}	VM1!P	Volume, periodical value, total	INT, BCD	0	0	8..199	no	VM01, VM02			O	O	O	O3	O	O		
Meter reading	VM1!R	Volume (meter), temperature converted (V _{tc}), forward, absolute, recent value for billing, total	INT, BCD	0	0	0..99, 101..124	yes	VM01, VM02						O				
Meter reading	VM1!RT	Volume (meter), temperature converted (V _{tc}), forward, absolute, recent value for billing, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	VM01, VM02						O				
Meter reading	VM2!	Volume (meter), measuring conditions (V _m), forward, absolute, current value, total	INT, BCD	0	0	0	no	VM03, VM04						A1				
Meter reading	VM2!B	Volume (meter), measuring conditions (V _m), forward, absolute, current value, total <i>Condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	VM03, VM04						E				
Meter reading	VM2!T	Volume (meter), measuring conditions (V _m), forward, absolute, current value, tariff 1-15	INT, BCD	1..15	0	0	no	VM03, VM04						O				
Meter reading ²⁵	VM2!P	Volume (meter), measuring conditions (V _m), forward, absolute, periodical value, total	INT, BCD	0	0	8..199	no	VM03, VM04						O3				

Meter reading	VM2!R	Volume (meter), measuring conditions (V_m), forward, absolute, recent value for billing, total	INT, BCD	0	0	0..99, 101..124	yes	VM03, VM04						O				
Meter reading	VM2!RT	Volume (meter), measuring conditions (V_m), forward, absolute, recent value for billing, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	VM03, VM04						O				
Meter reading	VM3!	Volume (meter), base conditions (V_b), forward, absolute, current value, total	INT, BCD	0	0	0	no	VM05, VM06						A1				
Meter reading	VM3!B	Volume (meter), base conditions (V_b), forward, absolute, current value, total <i>Exclusive condition: See OMS-S2 Annex R</i>	INT, BCD	0	0	3	no	VM05, VM06						E				
Meter reading	VM3!T	Volume (meter), base conditions (V_b), forward, absolute, current value, tariff 1-15	INT, BCD	1..15	0	0	no	VM05, VM06						O				
Meter reading ²⁵	VM3!P	Volume (meter), base conditions (V_b), forward, absolute, periodical value, total	INT, BCD	0	0	8..199	no	VM05, VM06						O3				
Meter reading	VM3!R	Volume (meter), base conditions (V_b), forward, absolute, recent value for billing, total	INT, BCD	0	0	0..99, 101..124	yes	VM05, VM06						O				
Meter reading	VM3!RT	Volume (meter), base conditions (V_b), forward, absolute, recent value for billing, tariff 1-15	INT, BCD	1..15	0	0..99, 101..124	yes	VM05, VM06						O				
Meter reading	VM4!	Volume, forward value	INT, BCD	0	0	0	no	VM07, VM08							O	O		
Meter reading	VM5!	Volume, backward value	INT, BCD	0	0	0	no	VM09, VM10							O	O		
	VV	Voltage in Volt																
Meter reading	VV1!	Voltage at phase L1, instantaneous value	INT, BCD	0	0	0	no	VV01		O								

Meter reading	VV2!	Voltage at phase L2, instantaneous value	INT, BCD	0	0	0	no VV02	O											
Meter reading	VV3!	Voltage at phase L3, instantaneous value	INT, BCD	0	0	0	no VV03	O											
	WS	Wind speed																	
Sensor reading	WS1!	Wind speed	INT, BCD	0	0	0	no WS01, WS02												S
	YD	Descriptors																	
Descriptor	YD1!	Subunit descriptor ¹⁷ <i>Condition: See OMS-S2 Annex K</i>	INT, BCD	0	0	0	no YD01	C	C	C	C	C	C	C	C	C	C		
Descriptor	YD1!T	Tariff descriptor <i>Condition: See OMS-S2 Annex K</i>	INT, BCD	1..15	0	0	no YD01	C	C	C	C	C	C	C	C	C	C		
Descriptor	YD2!P	Storage interval descriptor <i>Condition: See OMS-S2 Annex K</i>	INT, BCD	0	0	1..199	no YD02, YD03, YD04	C	C	C	C	C	C	C	C	C	C		
Descriptor	YD3!P	Storage range descriptor <i>Condition: See OMS-S2 Annex K</i>	INT, BCD	0	0	1..199	no YD05, YD06, YD07	C	C	C	C	C	C	C	C	C	C		

B.2.3 List of MB-Sensor-Tags

Description	MB-Tag	Pressure Device (18h)	Smoke Alarm Device (1Ah)	CO Alarm Device (1Dh)	Heat Alarm Device (1Eh)	Humidity Sensor	Moisture Sensor	Temperature Sensor	Light Sensor	Rainfall Sensor	pH Sensor	Anemometer	Glass Break Detector	Door/Window Contact	Locked Door/Window Detector	Water Leakage Detector	Air Quality Sensor	CO2 Sensor	Turbidity Sensor
Number of dismounts / removal counter	AD4!		O	O	O														
Number of test button operated counter	AD5!		O	O	O														
Number of alarms	AD6!		O	O	O														
Number of alarm mute switch operated counter	AD7!		O	O	O														
Number of obstacle detected counter	AD8!		O	O	O														
Number of smoke entries blocked	AD9!		O	O															
Number of smoke chamber defects	AD10!		O	O															
Number of self-test failed counter	AD11!		O	O	O														
Number of sounder defect counter	AD12!		O	O	O														
Chamber Pollution Level	AD13!		O	O															
Obstacle check distance	AD14!		O	O	O														
Carbon monoxide content	CC1!			M													O		
Carbon dioxide content	CC2!																O	M	
Electrical conductivity	CD1!													O	O				
Operating Time	DP5!	O	A1	A1	A1	O	O	O	O	O	O	O	O	O	O	O	O	O	O

On Time
Current date/time at time of transmission
Condition: See OMS-S2 Annex M OMS-UC-04

Date / Time of related sporadic event

Current date at time of transmission

Date of related sporadic event

Electrical Resistance

Serial number (not changeable number assigned by the manufacturer)

Identification number or full Application Layer Address

One byte Link Layer Address

Ownership number

Identification of the metering point

Unique message identification

Initial DIN address

Current DIN address

Sub Device Types

Irradiance, Radiant flux density

Illuminance

Luminous intensity

Reception level

Quality limit of reception level

Noise level

Error flags

Condition: See OMS-S2 Annex M OMS-UC-06

DP6!	O	A1	A1	A1	O	O	O	O	O	O	O	O	O	O	O	O	O	O
DT1!	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1
DT1!Xn		O2	O2	O2												O2	O2	
DT2!	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1	O1
DT2!Xn		O2	O2	O2												O2	O2	
ER1!													O	O				
ID1!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID2!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID3!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID4!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID5!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID6!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID7!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID8!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
ID11!	O	O	O	O	M	M	M	M	M	M	M	M	M	M	M	M	M	M
IR1!								O										
LT1!								A1										
LT2!								A1										
MM1!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM1!I	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM1!E	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM2!	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C

Error flags (standard) 14

Condition: See OMS-S2 Annex M OMS-UC-06

Operator specific data (reserved for the operator)

Currently selected application

Condition: See OMS-Se Annex M OMS-UC-14

Remaining battery lifetime

Battery status

Status bits for pressure sensor

Status bits for CO alarm devices

Status bits for smoke alarm devices

Status bits for "Door/Window Contact Sensor" and "Locked Door/Window Detector"

Status bits for heat alarm device

Moisture in %

Noise

pH value

defined Pressure, absolute, at base conditions (pb)

Defined pressure, absolute

Upper pressure threshold

Lower pressure threshold

Particles as unspecific range [$\mu\text{g}/\text{m}^3$]

Particles as PM1 [$\mu\text{g}/\text{m}^3$]

MM3!	C	C	C	C	M	M	M	M	M	M	M	M	M	M	M	M	M	M
MM4!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM6!	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C
MM8!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM12!	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O	O
MM13!	M																	
MM14!			M															
MM15!		M																
MM16!													M	M				
MM17!				M														
MO1!						M												
ND1!												A1						
PH1!										M								
PR1!	A1																	
PR2!	A1																	
PR3!	M21																	
PR4!	M21																	
PT1!																O	O	
PT2!																O	O	

Particles as PM2.5 [$\mu\text{g}/\text{m}^3$]	PT3!																O	O	
Particles as PM10 [$\mu\text{g}/\text{m}^3$]	PT4!																O	O	
Particles as unspecific range [$10\text{e}5/\text{m}^3$]	PT5!																O	O	
Particles as PM1 [$10\text{e}5/\text{m}^3$]	PT6!																O	O	
Particles as PM2.5 [$10\text{e}5/\text{m}^3$]	PT7!																O	O	
Particles as PM10 [$10\text{e}5/\text{m}^3$]	PT8!																O	O	
Rainfall	RF1!								M										
Relative Humidity in %	RH1!				O	M		O									O		
Turbidity	TB1!																		M
Return temperature, current value <i>Condition: See OMS-S2 Annex M OMS-UC-07²³</i>	TC2!					O	O										O		
External Temperature	TC4!	O			M	O	O	M									O		
Minimum temperature limit value	TC5!		O	O	O			O											
Maximum temperature limit value	TC6!		O	O	O			O											
Tension	TS1!											A1							
VOC Content [ppb]	VC1!																A1	O	
VOC Content [$\mu\text{g}/\text{m}^3$]	VC2!																A1	O	
Flow rate <i>Condition: See CEN/TR 17167:2018 Annex C.2</i>	VF1!								O								O		
Wind speed	WS1!										M								

B.2.4 List of MB-Command-Tags

Type	MB-Tag	Description	Data field	Tariff [T]	Function [F]	Storage [X]	Final DIFE [FD] ¹¹	VIB-Type Reference ²⁴	Electricity (02h)	HCA (08h)	Cooling (0Ah;0Bh)	Comb. Heat/Cooling (0Dh)	Heat (04h;0Ch)	Gas (03h)	Cold Water (07h;16h)	Hot Water (06h;15h)	Breaker / Valve (20h; 21h)	Sensor Device
	***	General applicable for all MB-Data-Tag																
	arl***!	Add MB-Data-Tag (***) to readout list <i>Condition: See OMS-S2 Annex M OMS-UC-14</i>	No Data	According to MB-Data-Tag definition				arl[VIB-Type according to MB-Data-Tag]	C	C	C	C	C	C	C	C	C	
	drl***!	Remove MB-Data-Tag (***) from readout-list <i>Condition: See OMS-S2 Annex M OMS-UC-14</i>	No Data	According to MB-Data-Tag definition				drl[VIB-Type according to MB-Data-Tag]	C	C	C	C	C	C	C	C	C	
	XCT	Compliance Test Command																
Command to OMS end-device	XCT1!	Set test state of compliance test <i>Condition: See OMS-S2 Annex M OMS-UC-00</i>	INT, VarLen	0	0	0	no	CT01	C	C	C	C	C	C	C	C	C	
	XDC	Disconnector Control Command																
Command to OMS end-device	XDC1!	Set control state of breaker/valve ¹⁶ <i>Condition: See OMS-S2 Annex M OMS-UC-03</i>	INT	0	0	0	no	CL01	C					C	C	C	M	
	XDT	Date / Time (Time stamp)																



Command to OMS end-device	getDT2!D	Get last due date <i>Condition: See OMS-S2 Annex M OMS-UC-12a</i>	No Data	0	0	1	no	get[DT02]		C	C	C	C		C	C		
Command to OMS end-device	getDT2!N	Get next due date <i>Condition: See OMS-S2 Annex M OMS-UC-12a</i>	No Data	0	0	1	no	get[DT05]		C	C	C	C		C	C		
Command to OMS end-device	setDT2!N	Set next due date <i>Condition: See OMS-S2 Annex M OMS-UC-12a</i>	Type G	0	0	1	no	set[DT05]		C	C	C	C		C	C		
XEJ		Command Energy in Joule																
Command to OMS end-device	addEJ1!	Add energy to current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	add[EJ01], add[EJ02], add[EJ03]	C		C	C	C					
Command to OMS end-device	getEJ1!	Get energy import <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	No Data	0	0	0	no	get[EJ01], get[EJ02], get[EJ03]	C		C	C	C					
Command to OMS end-device	setEJ1!	Set energy import <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	set[EJ01], set[EJ02], set[EJ03]	C		C	C	C					
Command to OMS end-device	subEJ1!	Subtract energy from current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	sub[EJ01], sub[EJ02], sub[EJ03]	C		C	C	C					
XEW		Command Energy in Watt hour																
Command to OMS end-device	addEW1!	Add energy to current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	add[EW01], add[EW02], add[EW03]	C		C	C	C					
Command to OMS end-device	getEW1!	Get energy import <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	No Data	0	0	0	no	get[EW01], get[EW02], get[EW03]	C		C	C	C					
Command to OMS end-device	setEW1!	Set energy import <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	set[EW01], set[EW02], set[EW03]	C		C	C	C					



Command to OMS end-device	subEW1!	Subtract energy from current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	sub[EW01], sub[EW02], sub[EW03]	C		C	C	C					
	XID	Identification																
Command to OMS end-device	setID2!	Set Application Layer Address <i>Condition: See OMS-S2 Annex M OMS-UC-20a</i>	64INT	0	0	0	no	set[ID02]	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	XID2!	Set Application Layer Address <i>Condition: See OMS-S2 Annex P</i>	64INT	0	0	0	no	ID02	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	XID3!	Set one byte Link Layer Address <i>Condition: See OMS-S2 Annex P</i>	8INT	0	0	0	no	ID03	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	getID4!	Get ownership number <i>Condition: See OMS-S2 Annex M OMS-UC-12b</i>	No Data	0	0	0	no	get[ID04]	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	setID4!	Set ownership number <i>Condition: See OMS-S2 Annex M OMS-UC-12b</i>	INT, BCD, VarLen	0	0	0	no	set[ID04]	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	setID10!	Set device type	8INT	0	0	0	no	set[ID09]	O	O	O	O	O	O	O	O	O	
Command to OMS end-device	XID10!	Set device type <i>Condition: See OMS-S2 Annex P</i>	8INT	0	0	0	no	ID09	C	C	C	C	C	C	C	C	C	
Command to OMS end-device	setID11!	Set identification number	8BCD	0	0	0	no	set[ID02]	O	O	O	O	O	O	O	O	O	
Command to OMS end-device	XID11!	Set identification number <i>Condition: See OMS-S2 Annex P</i>	8BCD	0	0	0	no	ID02	C	C	C	C	C	C	C	C	C	
	XMM	Meter Management Command																
Command to OMS end-device	notMM2!	Masked clear binary coded error flag <i>Condition: See OMS-S2 Annex M OMS-UC-06</i>	INT	0	0	0	no	not[MM02]	C	C	C	C	C	C	C	C	C	



Command to OMS end-device	notMM3!	Masked clear binary coded error flag (standard) <i>Condition: See OMS-S2 Annex M OMS-UC-06</i>	INT	0	0	0	no	not[MM03]	C	C	C	C	C	C	C	C	C	C
Command to OMS end-device	clrMM3!	Clear all error flags (standard and manufacturer specific) <i>Condition: See OMS-S2 Annex M OMS-UC-06</i>	No Data	0	0	0	no	clr[MM03]	C	C	C	C	C	C	C	C	C	C
	XMM2!	Valid only until OMS-S2 V4.4.2 => Replaced by notMM2!																
	XMM3!	Valid only until OMS-S2 V4.4.2 => Replaced by notMM3!																
	XMM4!	Valid only until OMS-S2 V4.4.2 => Replaced by clrMM3!																
Command to OMS end-device	getMM6!	Get application selection <i>Condition: See OMS-S2 Annex M OMS-UC-14</i>	No Data	0	0	0	no	get[MM17]	C	C	C	C	C	C	C	C	C	C
Command to OMS end-device	setMM6!	Set application selection <i>Condition: See OMS-S2 Annex M OMS-UC-14</i>	No Data, INT	0	0	0	no	set[MM17]	C	C	C	C	C	C	C	C	C	C
	XVM	Volume Command																
Command to OMS end-device	addVM1!	Add volume to current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	add[VM01], add[VM02]						C	C	C		
Command to OMS end-device	getVM1!	Get volume, current value, total <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	No Data	0	0	0	no	get[VM01], get[VM02]						C	C	C		
Command to OMS end-device	setVM1!	Set volume, current value, total <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	set[VM01], set[VM02]						C	C	C		
Command to OMS end-device	subVM1!	Subtract volume from current value <i>Condition: See OMS-S2 Annex M OMS-UC-20b</i>	INT, BCD	0	0	0	no	sub[VM01], sub[VM02]						C	C	C		

B.3 VIB-Type List

B.3.1 Legend and Notes

VIB-Type list

n One or more Bits, according to tables 10, 12, 14, 15 of [EN 13757-3:2018].

Table footnotes

⁵⁰ 'Temperature converted value' is just applicable for device type 03h (gas). All other device types consider this data Point as 'normal value'.

B.3.2 List of VIB-Types

VIB-Type Reference	VIF / VIFE	Scaler+Unit/Type	Remark
AD Alarm Devices (CO and Smoke Alarm)			
AD04	0111 1100 0000 0011 0100 1001 0101 0101 0010 0011	# number	Number of dismounts / removal counter (ASCII-Coding: "#UI", Number of Un-Installations)
AD05	0111 1100 0000 0011 0101 0100 0100 0110 0010 0011	# number	Number of test button operated counter (ASCII-Coding: "#FT", Number of Function Tests)
AD06	0111 1100 0000 0011 0100 1100 0100 0001 0010 0011	# number	Number of smoke / CO alarms (ASCII-Coding: "#AL", Number of Alarms)
AD07	0111 1100 0000 0011 0100 1101 0100 0001 0010 0011	# number	Number of alarm mute switch operated counter (ASCII-Coding: "#AM", Number of Alarm Muted)
AD08	0111 1100 0000 0011 0100 0100 0100 1111 0010 0011	# number	Number of obstacle detected counter (ASCII-Coding: "#OD", Number of Obstacle Detected)

AD09	0111 1100 0000 0011 0100 0010 0101 0011 0010 0011	# number	Smoke entries blocking cumulated counter (ASCII-Coding: "#SB", Number of Smoke entries Blocked)
AD10	0111 1100 0000 0100 0100 0100 0100 0011 0101 0011 0010 0011	# number	Smoke chamber defect cumulated counter (ASCII-Coding: "#SCD", Number of Smoke Chamber Defects)
AD11	0111 1100 0000 0011 0100 0110 0101 0011 0010 0011	# number	Number of self-test failed counter (ASCII-Coding: "#SF", Number of self-test Failed)
AD12	0111 1100 0000 0011 0100 0100 0101 0011 0010 0011	# number	Number of sounder defect counter (ASCII-Coding: "#SD", Number of Sounder Defect)
AD13	0111 1100 0000 0011 0101 0000 0100 0011 0010 0101	% percentage	Percentage of Chamber Pollution Level (ASCII-Coding: "%CP")
AD14	1111 1101 1111 1101 0010 1100	# number	Number of dismounts / removal counter
AD15	1111 1101 1111 1101 0010 1101	# number	Number of test button operated counter
AD16	1111 1101 1111 1101 0010 1110	# number	Number of alarms
AD17	1111 1101 1111 1101 0010 1111	# number	Number of alarm mute switch operated counter
AD18	1111 1101 1111 1101 0011 0000	# number	Number of obstacle detected counter
AD19	1111 1101 1111 1101 0011 0001	# number	Smoke entries blocking cumulated counter
AD20	1111 1101 1111 1101 0011 0010	# number	Smoke chamber defect cumulated counter
AD21	1111 1101 1111 1101 0011 0011	# number	Number of self-test failed counter

AD22	1111 1101 1111 1101 0011 0100	# number	Number of sounder defect counter
AD23	1111 1101 1111 1101 0011 1001	percentage 0-100%	Percentage of Chamber Pollution Level
CA Current [A]			
CA01	1111 1101 1101 nnnn 1111 1100 0000 0001	A 10e-12 ... 10e+3	Curr_L1
CA02	1111 1101 1101 nnnn 1111 1100 0000 0010	A 10e-12 ... 10e+3	Curr_L2
CA03	1111 1101 1101 nnnn 1111 1100 0000 0011	A 10e-12 ... 10e+3	Curr_L3
CA04	1111 1101 1101 nnnn 1111 1100 0000 0100	A 10e-12 ... 10e+3	Curr_N
CC Carbon Oxide Content			
CC01	0111 1100 0000 0011 0011 0001 0100 1111 0100 0011	ppm 10e0	Carbon monoxide content (ASCII-Coding: "CO1" for Carbon Monoxide)
CC02	0111 1100 0000 0011 0011 0010 0100 1111 0100 0011	ppm 10e0	Carbon dioxide content (ASCII-Coding: "CO2" for Carbon Dioxide)
CC03	1111 1101 1111 1101 0001 001n	ppm 10e+0 ... 10e+1	Carbon monoxide content
CC04	1111 1101 1111 1101 0001 000n	ppm 10e+0 ... 10e+1	Carbon dioxide content
CD Conductivity			
CD01	0111 1100 0000 0011 0011 0001 0100 0100 0100 0011	µS/cm 10e0	electrical conductivity in µS/cm (ASCII-Coding: "CD1" for Conductivity 1)
CL Control			
CL01	1111 1101 0001 1111		disconnecter control state
CL02	1111 1101 0001 1010		output state
CT Compliance Test			
CT01	1111 1101 1001 1111 0001 1101		compliance test
DI Distances			
DI01	0111 1100 0000 0010 0110 1101 0110 1101	mm	Distance (ASCII-Coding: "mm" for millimetre)
DI02	0111 1100 0000 0010 0110 1101 0110 0011	cm	Distance (ASCII-Coding: "cm" for centimetre)
DI03	1111 1101 1111 1101 0011 101n	10e+0 mm (mm, cm)	Distance

DI04	1111 1101 1111 1101 0010 0011	liters/mm²	Rainfall
DP	Duration/Period		
DP01	0111 01nn	s, min, h, d	actuality dur.
DP02	0111 00nn	s, min, h, d	average dur.
DP03	1111 1101 0011 110n	s, min	Period of nominal transmission
DP04	Valid only until OMS-S2 V4.1.2. => Replaced by YD03		
DP05	0010 01nn	s, min, h, d	Operation time (Duration of accumulation)
DP06	0010 00nn	s, min, h, d	On time (Duration since power up)
DT	Date / Time (Duration and Time stamp)		
DT01	0110 1101	Date+Time / Time	forward
DT02	0110 1100	Date	forward
DT03	1110 1101 0011 1100	Date+Time / Time	backward
DT04	1110 1100 0011 1100	Date	backward
DT05	1110 1100 0111 1110	Date; future date	forward
EC	Energy [Mcal]		
EC01	1111 1011 0000 11nn	Mcal 10e-1 ... 10e2	forward
EC02	1111 1011 1000 11nn 0011 1100	Mcal 10e-1 ... 10e2	backward
EJ	Energy [GJ]		
EJ01	0000 1nnn	GJ 10e-9 ... 10e-2	forward
EJ02	1111 1011 0000 100n	GJ 10e-1 ... 10e0	forward
EJ03	1111 1011 1000 100n 0111 1101	GJ 10e+2 ... 10e+3	forward
EJ04	1000 1nnn 0011 1100	GJ 10e-9 ... 10e-2	backward
EJ05	1111 1011 1000 100n 0011 1100	GJ 10e-1 ... 10e+0	backward
EJ06	1111 1011 1000 100n 1111 1101 0011 1100	GJ 10e+2 ... 10e+3	backward
ER	Electrical Resistance		
ER01	0111 1100 0000 0011 0110 1101 0110 1000 0100 1111	Ohm 10e+0	Resistance (ASCII-Coding: "Ohm")
EW	Energy [kWh]		
EW01	0000 0nnn	kWh 10e-6 ... 10e+1	forward
EW02	1111 1011 0000 000n	kWh 10e+2 ... 10e+3	forward
EW03	1111 1011 1000 000n 0111 1101	kWh 10e+5 ... 10e+6	forward

EW04	1000 0nnn 0011 1100	kWh 10e-6 ... 10e+1	backward
EW05	1111 1011 1000 000n 0011 1100	kWh 10e+2 ... 10e+3	backward
EW06	1111 1011 1000 000n 1111 1101 0011 1100	kWh 10e+5 ... 10e+6	backward
EW07	1000 0nnn 1111 1100 0001 0000	kWh 10e-6 ... 10e+1	abs.
EW08	1111 1011 1000 000n 1111 1100 0001 0000	kWh 10e+2 ... 10e+3	abs.
EW09	1111 1011 1000 000n 1111 1101 1111 1100 0001 0000	kWh 10e+5 ... 10e+6	abs.
FR Frequency [Hz]			
FR01	1111 1011 0010 11nn	Hz 10e-3 ... 10e0	mains power frequency
HC Heat Cost Allocation unit			
HC01	0110 1110	HCA 10e+0	signed
HC02	1110 1110 1111 1100 0001 0001	HCA 10e+0	unsigned
ID Identification Numbers			
ID01	0111 1000		Fabrication number
ID02	0111 1001		(Enhanced) identification
ID03	0111 1010		Primary address
ID04	1111 1101 0001 0001		Ownership number
ID05	1111 1101 0001 0000		Metering Point ID
ID06	1111 1101 0000 1000		Unique message identification
ID09 ⁵²	1111 1101 0000 1001		Device type
ID10	1111 1101 1111 1101 0000 0001	list of sub device types	see [prEN13757-3:2023] Table 20
IR Irradiance			
IR01	0111 1100 0000 0011 0011 0001 0101 0010 0100 1001	W/m ² 10e0	radiant flux density (ASCII-Coding: "IR1" for Irradiance 1)
IR02	1111 1101 1111 1101 0010 0001	W/m ² 10e0	radiant flux density
LT Light			
LT01	0111 1100 0000 0010 0111 1000 0110 1100	lx 10e0	Illuminance (ASCII-Coding: "lx" for lux)
LT02	0111 1100 0000 0010 0110 0100 0110 0011	cd 10e0	Luminous intensity (ASCII-Coding: "cd" for candela)
LT03	1111 1101 1111 1101 0001 1111	lx 10e0	Illuminance (lux)
LT04	1111 1101 1111 1101 0010 0000	cd 10e0	Luminous intensity (candela)

MM Meter Management				
MM01	1111 1101 0111 0001	dBm	Reception or noise level	
MM02	1111 1101 0001 0111	binary	Error flags	
MM03	1111 1101 1001 0111 0001 1101	binary	Error flags (standard)	
MM04	1111 1101 0010 1010		Operator specific data	
MM05	Valid only until OMS-S2 V4.1.2. => Replaced by YD07		-	-
MM06	1111 1101 0110 0001	Register index	Cumulation Counter	
MM07	Valid only until OMS-S2 V4.4.2 => Replaced by not[MM02]		-	
MM08	Valid only until OMS-S2 V4.4.2 => Replaced by not[MM03]		-	
MM09	1111 1101 0111 0100	days	Remaining battery life time	
MM10	1111 1101 1111 1101 0000 0010	month(s)	Remaining battery life time	
MM11	Valid only until OMS-S2 V4.4.2 => Replaced by clr[MM03]		-	
MM12	0111 1100 0000 0011 0101 0011 0100 0010 0010 0101	% percentage	Percentage of Battery Status (ASCII-Coding: "%BS")	
MM13	0111 1100 0000 0011 0011 0001 0101 0011 0100 0100	binary	Status bits for pressure device see [OMS-S2], Annex C table C.5 (ASCII-Coding: "DS1" for Device Status1)	
MM14	0111 1100 0000 0011 0011 0010 0101 0011 0100 0100	binary	Status bits for CO alarm devices, see [OMS-S2], Annex C table C.4 (ASCII-Coding: "DS2" for Device Status 2)	
MM15	0111 1100 0000 0011 0011 0011 0101 0011 0100 0100	binary	Status bits for smoke alarm devices, see [OMS-S2], Annex C table C.3 (ASCII-Coding: "DS3" for Device Status 3)	

MM16	0111 1100 0000 0011 0011 0100 0101 0011 0100 0100	binary	Status bits for "Door/Window Contact Sensor" and "Locked Door/Window Detector", see [OMS-S2], Annex C table C.6 (ASCII-Coding: "DS4" for Device Status 4)
MM17	1111 1101 1111 1101 0000 0000	binary	Currently selected application
MM18	1111 1101 1111 1101 0011 1000	% percentage	Battery Status
MM19	1111 1101 1111 1101 0100 0000	binary	Status bits for pressure sensor see [prEN13757], table 20
MM20	1111 1101 1111 1101 0100 0010	binary	Status bits for CO alarm devices, see [prEN13757], table 20
MM21	1111 1101 1111 1101 0100 0001	binary	Status bits for smoke alarm devices, see [prEN13757], table 20
MM22	1111 1101 1111 1101 0100 0100	binary	Status bits for "Door/Window Contact Sensor" and "Locked Door/Window Detector", see [prEN13757], table 20
MM23	1111 1101 1111 1101 0100 0011	binary	Status bits for heat alarm device, see [prEN13757], table 20
ND Noise			
ND01	0111 1100 0000 0011 0100 0001 0100 0010 0110 0100	dBA 10e0	Decibel A-weighting (ASCII-Coding: "dBA")
ND02	1111 1101 1111 1101 0010 0100	dBA 10e0	Decibel A-weighting
PD Phase in Degree [°]			
PD01	1111 1011 1010 1010 1111 1100 0000 0101	° 10e-1	Volt_L1-L2
PD02	1111 1011 1010 1010 1111 1100 0000 0110	° 10e-1	Volt_L2-L3
PD03	1111 1011 1010 1010 1111 1100 0000 0111	° 10e-1	Volt_L3-L1
PD04	1111 1011 1010 1011 1111 1100 0000 0001	° 10e-1	Curr_L1
PD05	1111 1011 1010 1011 1111 1100 0000 0010	° 10e-1	Curr_L2
PD06	1111 1011 1010 1011 1111 1100 0000 0011	° 10e-1	Curr_L3

PF	Pulse frequency		
PF01	Valid only until OMS-S2 V4.5.1 [PF01]		
PH	pH value		
PH01	0111 1100 0000 0010 0100 1000 0111 0000	pH 10e-1	potential of hydrogen (ASCII-Coding: "pH")
PH02	1111 1101 1111 1101 0010 0111	pH 10e-1	potential of hydrogen
PJ	Power [kJ/h]		
PJ01	0011 0nnn	kJ/h 10e-3 ... 10e+4	forward
PR	Pressure [bar]		
PR01	1110 10nn 0011 1110	bar 10e-3 ... 10e+0	pressure at base condition
PR02	1110 10nn 1111 0011 0011 1110	bar 10e-6 ... 10e-3	pressure at base condition
PR03	0110 10nn	bar 10e-3 ... 10e+0	pressure value
PR04	1110 10nn 0111 0011	bar 10e-6 ... 10e-3	pressure value
PR05	1110 10nn 0100 1000	bar 10e-3 ... 10e+0	pressure upper limit
PR06	1110 10nn 1100 1000 0111 0011	bar 10e-6 ... 10e-3	pressure upper limit
PR07	1110 10nn 0100 0000	bar 10e-3 ... 10e+0	pressure lower limit
PR08	1110 10nn 1100 0000 0111 0011	bar 10e-6 ... 10e-3	pressure lower limit
PT	Particles		
PT01	0111 1100 0000 0011 0011 0001 0101 0100 0101 0000	µg/m³ 10e0	unspecific range (ASCII-Coding: "PT1")
PT02	0111 1100 0000 0011 0011 0010 0101 0100 0101 0000	µg/m³ 10e0	PM1 (ASCII-Coding: "PT2", Particles 2)
PT03	0111 1100 0000 0011 0011 0011 0101 0100 0101 0000	µg/m³ 10e0	PM2,5 (ASCII-Coding: "PT3", Particles 3)
PT04	0111 1100 0000 0011 0011 0100 0101 0100 0101 0000	µg/m³ 10e0	PM10 (ASCII-Coding: "PT4", Particles 4)
PT05	0111 1100 0000 0011 0011 0101 0101 0100 0101 0000	1/m³ 10e5	unspecific range (ASCII-Coding: "PT5", Particles 5)
PT06	0111 1100 0000 0011 0011 0110 0101 0100 0101 0000	1/m³ 10e5	PM1 (ASCII-Coding: "PT6", Particles 6)
PT07	0111 1100 0000 0011 0011 0111 0101 0100 0101 0000	1/m³ 10e5	PM2,5 (ASCII-Coding: "PT7", Particles 7)

PT08	0111 1100 0000 0011 0011 1000 0101 0100 0101 0000	1/m³ 10e5	PM10 (ASCII-Coding: "PT8", Particles 8)
PT09	1111 1101 1111 1101 0001 0111	µg/m³ 10e0	unspecific range
PT10	1111 1101 1111 1101 0001 1000	µg/m³ 10e0	PM1
PT11	1111 1101 1111 1101 0001 1001	µg/m³ 10e0	PM2,5
PT12	1111 1101 1111 1101 0001 1010	µg/m³ 10e0	PM10
PT13	1111 1101 1111 1101 0001 1011	1/m³ 10e5	unspecific range
PT14	1111 1101 1111 1101 0001 1100	1/m³ 10e5	PM1
PT15	1111 1101 1111 1101 0001 1101	1/m³ 10e5	PM2,5
PT16	1111 1101 1111 1101 0001 1110	1/m³ 10e5	PM10
PW Power [W]			
PW01	0010 1nnn	W 10e-3 ... 10e+4	forward
PW03	1010 1nnn 0011 1100	W 10e-3 ... 10e+4	backward
PW04	1111 1011 0111 1nnn	W 10e-3 ... 10e+4	cum. forward
PW06	1111 1011 1111 1nnn 0011 1100	W 10e-3 ... 10e+4	cum. backward
PW07	1010 1nnn 1111 1100 0001 0000	kW 10e-6 ... 10e+1	abs.
PW08	1111 1011 1010 100n 1111 1100 0001 0000	kW 10e+2 ... 10e+3	abs.
PW09	1010 1nnn 1111 1100 0000 1100	kW 10e-6 ... 10e+1	delta
PW10	1111 1011 1010 100n 1111 1100 0000 1100	kW 10e+2 ... 10e+3	delta
RE Reactive Energy [kvarh]			
RE01	1111 1011 0000 001n	kvarh 10e0 ... 10e+1	forward
RE02	1111 1011 1000 001n 0111 0nnn	kvarh 10e-6 ... 10e+2	forward
RE03	1111 1011 1000 001n 0011 1100	kvarh 10e0 ... 10e+1	backward
RE04	1111 1011 1000 001n 1111 0nnn 0011 1100	kvarh 10e-6 ... 10e+2	backward
RH Relative Humidity [%]			
RH01	1111 1011 0001 101n	% 10e-01 ... 10e0	relative humidity
RH02	0111 1100 0000 0011 0011 0010 0100 1000 0101 0010	% 10e0	Moisture Level (ASCII-Coding: "RH2")
RH03	1111 1101 1111 1101 0011 1110	% 10e0	Moisture Level
RP Reactive Power [kvar]			
RP01	1111 1011 0001 01nn	kvar 10e-3 ... 10e+0	forward
RP02	1111 1011 1001 01nn 0011 1100	kvar 10e-3 ... 10e+0	backward
TB Turbidity			

TB01	0111 1100 0000 0011 0101 0101 0100 1110 0100 0110	FNU 10e0	Formazin Nephelometric Units (ASCII-Coding: "FNU")
TB02	1111 1101 1111 1101 0010 0101	FNU 10e0	Formazin Nephelometric Units
TC Temperature [°C]			
TC01	0101 10nn	°C 10e-3 ... 10e+0	flow
TC02	0101 11nn	°C 10e-3 ... 10e+0	return
TC03	1101 10nn 0011 1110	°C 10e-3 ... 10e+0	base condition
TC04	0110 01nn	°C 10e-3 ... 10e+0	external temperature
TC05	1111 1011 0111 01nn	°C 10e-3 ... 10e+0	Temperature Limit
TS Tension			
TS01	0111 1100 0000 0010 0100 1101 0100 1110	Nm/m²	tension of surfaces in Newton Meters (ASCII-Coding: "NM")
VC VOC Content			
VC01	0111 1100 0000 0011 0011 0001 0100 0011 0101 0110	ppb 10e0	(ASCII-Coding: "VC1" for VOC Content 1)
VC02	0111 1100 0000 0011 0011 0010 0100 0011 0101 0110	µg/m³ 10e0	(ASCII-Coding: "VC2" for VOC Content 2)
VC03	1111 1101 1111 1101 0001 010n	ppb 10e0 .. 10e+1	Volatile Organic Compounds
VC04	1111 1101 1111 1101 0001 0110	µg/m³ 10e0	Volatile Organic Compounds
VF Volume Flow [m³ / h]			
VF01	0011 1nnn	m³/h 10e-6 ... 10e+1	normal / temp. Converted ⁵⁰
VF02	1011 1nnn 0011 1010	m³/h 10e-6 ... 10e+1	meas. condition
VF03	1011 1nnn 0011 1110	m³/h 10e-6 ... 10e+1	base condition
VM Volume [m³]			
VM01	0001 0nnn	m³ 10e-6 ... 10e+1	normal / temp. Converted ⁵⁰
VM02	1001 0nnn 0111 1101	m³ 10e-3 ... 10e+4	normal / temp. Converted ⁵⁰
VM03	1001 0nnn 0011 1010	m³ 10e-6 ... 10e+1	meas. condition
VM04	1001 0nnn 1111 1101 0011 1010	m³ 10e-3 ... 10e+4	meas. condition
VM05	1001 0nnn 0011 1110	m³ 10e-6 ... 10e+1	base condition

VM06	1001 0nnn 1111 1101 0011 1110	m ³ 10e-3 ... 10e+4	base condition
VM07	1001 0nnn 0011 1011	m ³ 10e-6 ... 10e+1	forward volume
VM08	1001 0nnn 1111 1101 0011 1011	m ³ 10e-3 ... 10e+4	forward volume
VM09	1001 0nnn 0011 1100	m ³ 10e-6 ... 10e+1	backward volume
VM10	1001 0nnn 1111 1101 0011 1100	m ³ 10e-3 ... 10e+4	backward volume
VV Voltage [V]			
VV01	1111 1101 1100 nnnn 1111 1100 0000 0001	V 10e-9 ... 10e6	Volt_L1
VV02	1111 1101 1100 nnnn 1111 1100 0000 0010	V 10e-9 ... 10e6	Volt_L2
VV03	1111 1101 1100 nnnn 1111 1100 0000 0011	V 10e-9 ... 10e6	Volt_L3
WS Wind speed			
WS01	0111 1100 0000 0011 0011 0001 0101 0011 0101 0111	m/s 10e0	(ASCII-Coding: "WS1" for Wind Speed)
WS02	1111 1101 1111 1101 0010 0010	m/s 10e0	Wind Speed
YD Descriptor			
YD01	1111 1101 0010 0011		Descriptor tariff and subunit
YD02	1111 1101 0010 01nn	s, min, h, d	Storage interval
YD03	1111 1101 0010 1000	month	Storage interval
YD04	1111 1101 0010 1001	years	Storage interval
YD05	1111 1101 0010 0000		First storage no. for cyclic storage
YD06	1111 1101 0010 0001		Last storage no. for cyclic storage
YD07	1111 1101 0010 0010		Size of storage block